

MTC-H series hot flow channel temperature control box instruction manual

Professional manufacturer of hot duct temperature control box



ASPIRE TEMPERATURE CONTROLS, HEATERS AND MOULD SOLUTION.

Address:- S No, 183/4, Kate Bulding, Kata Nagar, Pawana Nagar, Pimple Saudagar,

Pimpri, Dist.:- Pune, Maharashtra, Pin-411017, Mob No:- 99 7005 7771

Email Id:- sales.india@aspirechams.com, ops.india@aspirechams.com

MTC-H series products




I product introduction

Product name: hot duct temperature


control box

Model: MTC-H series

- Small and exquisite, highly integrated
- Sam touch screen display control
- Chinese/English color screen display
- One card and dual control
- Practical and rich functions
- Flexible replacement of temperature




Convenient touch screen operation interface



Power indicator light
Running indicator light
Communication signal

Base roller design :It is more convenient to move the product



II product advantages

Mono-unit can support 128

One-card dual-controlled

partition control

Simple parameter setting,
stable and reliable equipment

Online fault detection function,
stable operation of equipment

Specifications and parameters

1. Control temperature difference: $+1^{\circ}\text{C}$
2. Cold-end compensation error: $\leq +1^{\circ}\text{C}$ temperature coefficient
3. Temperature control range K-type force thermoelectric 0-450°C
4. Total output power: 66KW (maximum)
5. Single maximum output current: 15A
6. Alarm Fan Guo: 0-100°C free setting
7. Suitable for thermocouple model K, type
8. Working power supply AC220V (three-phase four-wire 380v)
9. Digital PID adjustment

10. Working environment: -10°C-60°C relative temperature, 35% -85% relative humidity

11. The maximum number of control circuits in a single unit 128

- 1. color screen display
- 2. Chinese information alarm
- 3. Current and output ratio display
- 4. Tips for fuse damage
- 5. Thermal and electrical fault detection
- 6. Heating pipe fault detection
- 7. All-industrial electronic components
- 8. Linear voltage control output for better protection Heating pipe
- 9. Overvoltage alarm
- 10. 8inch touch screen centralized control (optional)
- 11. RS485 communication interface (optional)

ASPIRE TEMPERATURE CONTROLS, HEATERS AND MOULD SOLUTION.

Address:- S No, 183/4, Kate Bulding, Kata Nagar, Pawana Nagar, Pimple Saudagar, Pimpri, Dist.:- Pune, Maharashtra, Pin-411017, Mob No:- 99 7005 7771

Email Id:- sales.india@aspirechams.com, ops.india@aspirechams.com

III Foldable display screen of temperature control box




The screen can be folded. A single page of the touch screen operation interface can display 10 temperature control areas, and a single cell can display a temperature control area. In the page, a single temperature control area can be opened or closed, and the temperature control area serial number, actual temperature, setting temperature, operation status, fault and alarm prompt information, replication loop, mold model, current and current output ratio, lock screen with global temperature setting function, semi-temperature (insulation) function, and temperature replication function are displayed.


IV Operation interface



Parameter Interface



Temperature setting interface




Globle Settings

ASPIRE TEMPERATURE CONTROLS, HEATERS AND MOULD SOLUTION.

Address:- S No, 183/4, Kate Bulding, Kata Nagar, Pawana Nagar, Pimple Saudagar, Pimpri, Dist. :- Pune, Maharashtra, Pin-411017, Mob No:- 99 7005 7771
Email Id:- sales.india@aspirechams.com, ops.india@aspirechams.com

V Operation instructions



Operation

Turn on all empty lights and make sure that all the power indicator lights of the temperature control card are on.

Switch

Press the "On/off" button on the home page of the screen to show that you want to open the system, click the "Yes" button, and the system is on. Press the "on/off" button on the home page of the screen, and it shows that you want to close the system. Click the "Yes" button, and the system is closed.

Temperature setting

Press the raised button next to the loop "SV" that needs to be set, the screen jumps out of the input keyboard interface, manually enter the required temperature, and then press the "Confirm" key to complete the temperature input setting of this circuit."

Fast temperature setting

If you need to set multiple loops to the same temperature: for example, set the same temperature for loops 1 to 10. After the temperature of the first circuit is set, copy loop 1 will appear at the bottom of the screen (press the "COPY" key to cancel the copy command), and then press the "COPY" key of the 2- The 9 loop is quickly set at the same temperature as the 1st circuit. Press the global setting button on the homepage to enter the global temperature setting interface, which can set the temperature of all loops at one time.

Global temperature setting

Click the global settings button on the homepage to enter the settings. Click PV/SV on the page, enter the parameters corresponding to PV/SV, and click OK to set up.

> Parameters are not set

Press the raised button next to the loop "SV" that needs to be set, the screen jumps out of the input keyboard interface, and click 'parameters' to enter the parameter setting interface. Press the up arrow or down arrow to move the cursor to select the required parameters. After selecting the required parameters, you can press the numeric keyboard or the 'D+, D-' key to adjust the parameters.

> Restore factory settings

Press the 'Restore' key to return to the initial value.

> System settings

Press the 'System Settings' button, enter the system settings interface, and press the up or down arrow to move the cursor to select the required parameters. After selecting the required parameters, you can press the numeric keyboard or 'D+, D-' keys to adjust the parameters. (Language and mold model settings can be set)

> Mold model setting, mold model setting, language setting, address setting, baud rate setting, automatic lock screen setting, °C or °F switching

Press the system button, press the arrow up or down key, select parameter 1/parameter 2/parameter 3/parameter 4/parameter 5/para 6, and then press D+ or D- to set the temperature switch of mold model/language/address/baud rate/automatic lock screen/°C and °F.

> Global settings

Click the Global Settings button on the main page to enter the settings. Click the global on or global off button to turn on or off the power supply in all temperature control areas of the device. Click the TCJ or TCK button to switch the thermocouple models in all temperature control areas of the equipment to type J or K.

Common faults

1. After turning on the air switch, the temperature control card screen emits a continuous red alarm sound zero line and the fire line is reversed or lacks zero line.
2. After booting, the temperature control card makes a continuous alarm sound. The thermocouple is disconnected, and the heater is short-circuited or open. Please check the thermocouple and Heater or check whether the connection cable is loose.
3. After starting up, the temperature keeps rising, and the output current remains unchanged until the high-temperature alarm silicon control short circuit and control card appear. It needs to be repaired.
4. The temperature control is unstable and the output current value fluctuates greatly and there is a lack of zero wire. Please check the power supply plug to troubleshoot.

Precautions

5. If the POWER signal light of the temperature control card is not on, please check whether the power supply is turned on or whether there is a lack of phase.
6. If the startup prompts the heating short circuit, please detect whether the temperature sensor and heater are reversed. If there is no reverse connection, just increase the P23 parameter.
7. If the temperature control is unstable, the P17 can be turned on.

ASPIRE TEMPERATURE CONTROLS, HEATERS AND MOULD SOLUTION.

Address:- S No, 183/4, Kate Bulding, Kata Nagar, Pawana Nagar, Pimple Saudagar, Pimpri, Dist.:- Pune, Maharashtra, Pin-411017, Mob No:- 99 7005 7771

Email Id:- sales.india@aspiretchams.com, ops.india@aspiretchams.com

1. Before replacing the mold and pulling out the connection cable, please turn off the air switch on the back plate of the temperature control box.
2. This product is a metal shell, which needs to be well grounded to prevent electric shock.
3. If you encounter an unsolvable fault, please do not disassemble the machine by yourself. You can seek the help of professional technicians.
4. Before connecting the mold, please check the wiring diagram of the temperature control box to ensure that it is consistent with the mold wiring diagram before starting up.

1.

Control parameter table

P1 mode setting automatic/manual P2

manual output 0%-100%

P3 model J/K

P4 alarm function alarm/disable P5

over-temperature range 0-50°C P6 Low

temperature range 0-50°C

P7 temperature correction -50°C-50°C P8

temperature unit°C/°F

P9 signal output mode continuous/pulse P10

soft start time 0-99min

P11 soft start output 0-100%

P12 temperature compensation value ambient temperature (cannot be set) P13 P

parameter initial value (can be set)

P14 I parameter initial value (can be set) P15

D parameter initial value (can be set) P16 D2

parameter initial value (setable)

P17 PID mode position/self-tuning/incremental (if you encounter unstable temperature control, you can turn on the self-tuning function)

P18 Serial Number 001-128 P19

Current Limit 5.0A-16.0A

P20 Restore Factory Settings Cancel/Reset

P21 communication settings cancellation/communication (touch screen version use) P22

Language Settings Chinese/EN

P23 short-circuit detection 20-99 (if you encounter a boot prompt heater short-circuit alarm prompt, just turn this parameter up)

P24 follow disable/0-128 (touch screen version use)

Distribution of power lines

Red (3 pieces)—Fire Blue (1 piece)--zero line Yellow and green (1)--ground wire